Declaration of Conformity

This product has been manufactured according to actual technical standards. The product is matching the requirements of the existing european and national guidelines. The Declaration of Conformity has been proofed. AMEWI Trade e.K. declares that this product is matching the basic requirements and remaining regulations of the guideline 2014/53/EU (RED). The declarations and documents are stored at the manufacturer and can be requested and applied there.

The full text of the declaration of conformity can be found at: https://amewi.com/Konformitaetserklaerungen


For additional questions to the product and conformity please contact: Amewi Trade e.K. Nikolaus-Otto-Str. 18, 33178 Borchen or via the website amewi.com



USER MANUAL

Security and Hazard Warnings

Warning! For damage, caused by disregarding of the manual, warranty expires! We are not liable for secondary failures, material or personal damage, caused by inproper usage or disregarding





The product is not allowed to get moist or wet. Even a drop down from a small height can cause damage to the product.

Battery Notice and Battery Disposal




Warning! Battery do not belong in childrens hands. A change of the battery has to be done by an adult person. Never mix chargable batteries with non-chargable batteries. Never mix fully charged batteries with almost emtpy batteries. Never mix batteries of different capacities. Never try to charge dry batteries. Take care of the correct polarity. Defective batteries belong to special waste. Never leave a charging battery unattended. For questions about the charging time please read the manual or ask the manufacturer.

The company AMEWI is registered below the WEEE Reg. Nr. DE93834722 at the foundation EAR and recycles all used electronic parts properly. Electric and electronical products are not allowed to put in household garbage. Please dispose the product at the end of the lifetime accroding to the actual laws. You as a customer are responsible by law for the return of all used batteries, a disposal over the household garbage is forbidden!



prohibition of disposal in household garbage. Additional notations for the critical heavy metal are: Cd=Cadmium, Hg=Quecksilver, Pb=lead (Label is placed on

Batteries containing hazardous substances are marked with the alongside symbols, which point to the



Based on RoHS labeling the manufacturer confirmes, that all limit values were taken care of at the time of manufacturing.



Batteries labeled with the recycling symbol can be put into used battery collecting tank. (Most supermarkets have) They are not allowed to be put into local household garbage.



AMEWI Trade e.K. is involved in the dual system for boxing over the company Firma Landbell AG. All used boxes are collected from partner companies (waste disposal contractor) at private customers (local household), sorted and properly utilized. The Involvement in a Dual Systems helps to save CO² Emissions.

8 + AGES

CRAWLER EXCAVATOR ACV730

Item No.: 22516




AMEWI TRADE e.K. Nikolaus-Otto-Str. 18, 33178 Borchen

FUNCTION INTRODUCTION OF REMOTE CONTROL


ATTENTION:


To use the accessory function, please buy accessories.





Left forward Right forward Left backward -Right backward


EXCAVATOR DRIVING CONTROL Left turn (press and hold Right turn (press and hold the left forward rotation) the right forward rotation)











6

7.4V 1200mAh

DICATOR LIGHT STATUS AT THE

Red light always lit + Green light flashes

When battery is charged, please pull off

the USB charger lead in time.

Uncharged state: red light always lit


DIGGING ARM AND PLATFORM CONTROL





















Installation of Remote Control Battery

1. Loosen the screw of battery cover by screwdriver and take out battery cover.




2. Put Three 1.5V AA non-rechargeable batteries (batteries need to be purchased separately) into the battery box to the right polarity at the bottom of remote control.




3. Install the battery cover and tighten the screw.



- 1. Take out and install battery correctly.
- 2. The non-rechargeable battery can't be charged.
- 3. The rechargeable battery can only be charged under custody of adults;
- 4. Different batteries or new and old batteries can't be used together;
- 6. The rechargeable battery should be taken out from model before charging.
- 7. Battery should be placed with correct polarity;
- 9. Short-circuit of battery terminal is forbidden;





Battery Installation Instructions:


- 5. Battery of same model or recommended model can be used;
- 8. The exhausted battery should be taken out from model;

2

1


INSTALLATION OF REMOTE-CONTROL MODEL BATTERY

1. Twist the battery cover latch to remove the




Battery cover latch Battery cover


3. Install the battery cover and twist



2. Connect the rechargeable battery pack to the power port of the demolition machine closely



1. This product is equipped with remote control of 2.4GHz. When a user operate it for the first time, please install batteries into model and remote control, then turn the power on, the model is turned on and frequency is automatically paired, and frequency pairing sound is given, beeps" indicates the frequency has been paired.



Control of light and sound





Press this button to turn on the sound,

and press once more to turn it off.






Press this button to turn on the light, and press once more to turn it off.

BATTERY CHARGING INSTRUCTIONS CHARGING METHODS BATTERY/USB PARAMETERS

Connect the white port of Li-Ion to USB Battery specifications: 18650 charging port, as shown in the Figure, and ensure port can be connected tightly and Intelligent USB balance charger with correctly, then insert the USB charging plug

> Input: 5.0V 1-2A Output:4.2V 800mAh X2

overcharge protection



Full charging state: Red and green light always lit Charging period: 4-5 hours

Charged state:

Precautions Of Li-lon

into power adapter, and perform charging.

1. Battery can be charged only by originally configured USB charger lead; 2. Be sure to charge with white big-socket port while not the red socket;

3. 7.4V Li-Po must be equipped with 5V USB charging plug;

4. The Li-Po with damaged appearance can't be charged.

to avoid fire hazards resulted from spontaneous combustion.

5. Li-Po must be charged in sheet iron box;

6. Battery should be charged within specified charging period.

Safe Usage Instructions for Li-Ion

• Li-Po is of higher danger compared with other batteries. Be sure to carefully read the instructions and follow precautions and charging methods before usage.

• This company won't bear any responsibility resulted from improper usage.

• It is strictly forbidden to charge Li-Po with non-original charger, to avoid explosion and fire hazards. Impact, dismantling, inverse connection of positive and negative polarities and incineratingbattery are strictly forbidden, to avoid short circuit resulted from metal objects' impacting positive and negative polarities of battery. And please prevent sharp objects from penetrating battery, to avoid catching fire of battery.

 Be prudent and careful to perform charging, to ensure charging can be performed within your visibility range.

• Charger should be out of reach of children to avoid danger.

• The degraded battery shouldn't be charged, otherwise, battery expansion, deformation,

explosion even fire hazard will occur, endangering safety and lives and properties. • The discarded batteries should be recovered by strictly following national or regional waste

disposal decrees, so as not to pollute environment.

咬口 汇纳/1592英文说明书-2019/9/22