1/16 Wolverine M10
100% Matal Version

Item No.: 23089
23099

FEATURES

2.4Ghz Remote Control
3:1 Gearbox
360° Turret Rotation
Realistic Tank Sounds
Full Scale RC Functions
Airsoft BB

Model shown is Original Metal Version



Open/Close Hatches ***Functional Suspension System*** ***Adjustable Track Tensioner***

AMEWI Trade e.K. Nikolaus-Ot to-St r. 18 33178 Borchen / Germany

1/16 Wolverine M10
100% Matal Version

CONTENTS

- 100% Metal Tank
- 2.4G 6 Channel Transmitter
- 2600 mAh LiPo battery
- Battery Charger
- Instruction Manual
- Spare Parts for Tracks

ATTENTION

Once you have turned the transmitter On, the Tank is ready to run. Before starting the Tank, please ensure that it is placed into Safe Mode. To place the Tank into safe mode, put the Right and Left Sticks in the middle position. Failure to do so may result in the Tank moving unexpectedly.

BATTERY INFORMATION

Battery Installation for Transmitter

Push down on the Battery Cover to remove it.
Place batteries inside the transmitter matching with its corresponding sign (+/-).
Install 8 AA batteries and replace cover. (Batteries not included)

Battery Installation for Tank

1. Release the Feifel Air Filtrers Pipe
2. Push down on the Starting Handel Plate
3. Remove the Upper Hull
4. Place 3300 Mah NI-MH Battery into Tank.(Included)
5. Replace the Hull back into place.

CONTROL METHODS

The Left Stick will return to the Middle position when not used. The Right Stick has 5 functions depending on the position.



1. Power ON or OFF

ON: Turn on the transmitter, and then turn on the Tank power.
OFF: Turn off the Tank power, and then turn off the transmitter.
Note: When your Tank has synced with the transmitter, there is no engine sound, but the Tank is now ready to be controlled.

2. Engine Sound ON or OFF

When you push the Right Stick to the bottom, and move the Left Stick to the Left, the Tank sound starts / stops.



3. Front Lights ON or OFF

To Turn the Tank front lights On / Off, push down the Right Stick and move the Left Stick to the Right.



4. Forward or Reverse

To move forward, push Left Stick up, keep Right Stick in middle.
To reverse, push Left Stick down, keep Right Stick in middle.



5. Turn Tank Left and Right

To move the Tank Left, press the Left Stick upward, press the Right Stick to Left.
To move the Tank Right, press the Left Stick upward, press the Right Stick to Right.



Super Spin 360° - To perform this action, you must push the Left Directional Stick Up or Down, while simultaneously pushing the Right Stick to the Left or Right Direction.

6. Machine Gun Fire

When you push the Right Stick to the bottom, and move the Left Stick to the Right, realistic German Tiger I Tank firing sound made by machine gun.



7. Barrel Up or Down

When you push up the Right Stick, and move the Left Stick to the Left / Right, the barrel is up / down.



8. Tank Barrel Shooting

For Infrared Version:
Press and hold the Right Stick in the up position.
You will also see the Tank barrel recoil with every shot.
For Airsoft Version:
Press and hold the Right Stick in the up position.
You will also hear a shot sound for each time you are shooting.



Multiplayer Infrared Tank Battles - If you have Two Infrared Tanks, you may engage in a Tank Battle with each other! After a certain amount of "Hits", your Tank will become immobilized. Infrared Tank Battles will also work with more than two Tanks!

AMEWI Trade e.K. Nikolaus-Otto-Str. 18 33178 Borchen / Germany